

BOTON HONGO PARO DE EMERGENCIA XB4-BS542



XB4-BS542

Urgent stop red mushroom pushbutton Ø50 (red)

Action Mode	Contact		Reference
	N/O + N/C		
Push-pull spring action	1	1	XB4-BT845
Circumgyrate spring action	1	1	XB4-BS8445
Key spring action (n°555)	1	1	XB4-BS9445
Push-pull	–	1	XB4-BT42
Circumgyrate	–	1	XB4-BS542
Key (n°555)	–	1	XB4-BS142