


Code No	Function	Stage
A301	1 Pole	1
A301A	2 Pole	1
A302	3 Pole	2
A302A	4 Pole	2
A303	5 Pole	3
A303A	6 Pole	3
A304	7 Pole	4
A304A	8 Pole	4



Connecting Diagram



Escutch Plate

