

WEEKLY PROGRAMMABLE TIMER

4. PULSE setting : ("P" displays at bottom - left corner of LCD)

Step	Key	Programming
1	Press H+&M+	Into pulse setting
2	Press ⌚&H+/M+	Setting pulse time range 1sec.-59min 59sec
3	Press ⌚&MANUAL	Confirm pulse time range
4	Press P	Into setting 1 on time (display 1 on)
5	Press H+/M+	Setting on time
6	Press D+	Select days of week, same everyday, MO-FR, MO-SA, SA SU, MO-WE, TH-SA, MO WE FR, TU TH SA, different everyday. (If same everyday, not press this key)
7	Repeat step 2-3	Setting 2-18 pulse
8	Press ⌚	End
9	Press H+&M+	Exit pulse

*If need not 18 pulse press "⌚" key to the end

5. Count down : ("d" displays at bottom - left corner of LCD)

Step	Key	Programming
1	Press P&⌚	Into count down
2	Press ⌚&H+/M+	Setting min/sec
3	Press MANUAL	Start count down
4	Press P	Return to start count down
5	Press P&⌚	Exit

6. Pause

Neither needn't the timer work nor delete the set programme, you could just press **⌚** and "MANUAL" for 3 seconds at the same time to make the timer "AUTO OFF" permanently (only can access when "ON AUTO" or "AUTO OFF"), in that case, the timer can not be changeover "⌚" displays at the bottom-left corner of LCD, press

⌚ and "MANUAL" to restore "AUTO OFF", and the timer turn to work normally.

7. Auto time error correction, weekly : ("7d" displays at bottom - left corner of LCD)

Step	Key	Programming
1	Press P&MANUAL	Into count
2	Press D+	Setting -30sec.-30sec
3	Press ⌚	Confirm

8. Timing

8.1 Press **⌚** and press **D+** repeatedly go to today

8.2 Press **⌚** and press **H+ /M+** to change hr./min

9. Having operated items mentioned above, please be sure to reset the ON or OFF according to the current time. press "MANUAL" in order to display at the bottom Line of the LCD

10. Check time : press "P" to check whether the time is set correctly or not

press "MANUAL" and then reset the time and week

press "⌚" to finish checking and setting, and the time will be display afterwards

11. Press "MANUAL" to turn on or off at will, except 5

12. Press "D+" and "H+" for 3 seconds to turn off, but the setting will be lost

13. Press "RESET" to restart, but the settings can not be restored

NOTE

- Time setting should according to the time sequence, couldn't be set crossly
- System with quit automatically if there's no operating within 10 seconds. And no data is saved. It will quit when setting finishes
- Function 3, 4, 5, can not be used simultaneously